

Gem

SERIES IV MODEL

INSTRUCTION BOOK
AND
SPARE PARTS LIST

'Gem' Series IV model

This instruction book has been written with the object of providing in the simplest possible manner a complete guide for the owner in the operation of the "Gem" Series IV Model. Detailed instructions for the larger maintenance operations, especially those which may become necessary after long service, are not included in this publication, as such work should be entrusted to the local "Gem" Service Distributor.



ROTARY HOESE LIMITED
WEST HORNDON, ESSEX, ENGLAND

Telephone : Herongate 361.

Cables : Rotavator, Brentwood

INDEX

ADJUSTMENTS

Carburettor Jets	14
Depth Control Lever	6
Engine Clutch	12
Rear Shield	8
Rotor Friction Drive	12
Road Wheels	13
Rotor Flange Weeder Blades	13
Throttle	6

AIR CLEANER

13

ATTACHMENTS

Depth Control Wheel	16
Extension Rims	17
Furrowing	16
Furrow Covering	16
Picktyne Rotor	17
Power Take-off Pulley	17
Roller Attachment	16
Soil Shredder	17
Waterproof Cover	17

COMMENCING CULTIVATION

7

CONTROLS

Clutch	6
Exhaust Valve	6
Handlebars	6
Reverse Gear	6
Rotor Gear	6
Rotor Depth	6
Starting Handle	6
Throttle	6
Travel Gears	6

CULTIVATING

Virgin Soil	8
Hilly Ground	8
Ploughland	8

DECARBONISING ENGINE

14

ENGINE TROUBLE CHART

10

LUBRICATION

Controls	10
Engine	9
Gear-box	10
Lubrication Chart	11
Rotor Drive Chain Box	10
Rotor Drive Dog Gear-box	9
Rotor Stub Axle	10

MAINTENANCE

Air Cleaner	13
Carburettor	14
Road Wheels	13
Rotor Friction Drive	12
Rotor Hoe Blades	13

NOTES FOR OPERATOR

9

NOTES ON CULTIVATION

8

ORDERING SPARE PARTS

18

PREPARING FOR WORK

7

REVERSE GEAR

6

SPARE PARTS DIAGRAMS AND LISTS


Plate No. 1	Crankcase and Cylinder Assembly	20
" 2	Crankshaft Assembly	22
" 3	Air Cleaner and Carburettor	24
" 4	Gear-box	26
" 5	Gear-box	28
" 6	Jackshaft, Chaincase and Rotor	30
" 7	Frame, Tank, Oil Filter and Road Wheels	34
" 8	Controls	36
" 9	Picktyne Rotor, Depth Control Wheel, Power Take-off, and Extension Rims	40
" 10	Soil Shredder, Furrowing and Furrow Covering Attachment, and Roller	42
" 11	Magneto	44

SPECIFICATION

5

STARTING AND STOPPING ENGINE

7



THE "GEM" Series IV Model.

SPECIFICATION

ENGINE

Air-cooled (Fan) Twin cylinder (in line vertical) 4-stroke (810 cc.).

BORE AND STROKE

3" diam. x 3½" stroke.

ENGINE SPEED

2,000 r.p.m.

FUEL TANK

Capacity 2 gallons

CLUTCH

High duty single dry plate.

GEAR-BOX

Three speed and reverse transmission by hardened gears running in oil. All shafts mounted on ball bearings. Differential gear for easy turning automatically locked when rotor is engaged.

SPEEDS

1st gear—87 m.p.h. 2nd gear—1.3 m.p.h.
3rd gear—1.83 m.p.h. Reverse gear—1.55 m.p.h.

ROTOR

Speed 172 r.p.m. 18" diam.

POWER TAKE-OFF PULLEY

10" diam. 4" face. 500 r.p.m. 1,309 ft. per min.

OVERALL DIMENSIONS OF MACHINE

Length 6' 8". Width (24" rotor) 2' 5".
(30" rotor) 2' 11".

WEIGHT

5½ cwt. approximately.

CONTROLS

THROTTLE

The throttle control lever is fitted under the right handlebar grip. By raising it the engine speed is increased; by pressing it down the engine speed is reduced. The twin engine is governed, the hand throttle being used for starting and idling. At all other times the governor has control.

CLUTCH

Control lever is mounted on left handlebar. Normal operation for forward travel, pull up lever to disengage drive, release to re-engage. To reverse machine, operate as follows: pull up clutch lever, move gear lever to reverse (which operates safety interlock), release clutch lever. No movement takes place until clutch lever is pushed down. Removal of pressure automatically stops machine. To disengage reverse gear, pull up clutch lever, move gear lever to neutral.

HANDLEBAR POSITIONING LEVER

This is mounted on the main frame and is situated between the gear levers. To swing the handlebars to either side, press the handlebar positioning lever down to its full extent and swing the handlebar to whichever side is desired.

HEIGHT OF HANDLEBARS

To adjust the height to suit the operator, remove the bolt at each end of the handlebar slide and select another hole in the lugs attached to the handlebars.

ROTOR GEAR CONTROL LEVER

The lever on the quadrant engages the rotor whilst pulling it back engages the lever forward disengages the rotor whilst pulling it back engages the rotor.

TRAVEL GEAR CONTROL LEVER

Operates in a 4-star quadrant, marked 1, 2, 3, R to indicate forward travel and reverse positions. Neutral position is central. To engage gear, move lever to required position. Note safety feature, clutch interlock with reverse gear, see instructions under "Clutch".

ROTOR DEPTH CONTROL LEVER

This is linked with the depth control skid, or wheel, and situated above the rotor shield. To lower the rotor for deeper work, the lever is raised to decrease the depth the lever is pushed down.

EXHAUST VALVE LIFTING LEVER

This is placed under the main frame over the centre of the rotor shield and lifting up decompresses the engine for easy starting.

THE ENGINE STARTING HANDLE

When this is not in use it is folded back on the rotor shield. When starting the engine, lift it out of the bracket and swing it forward until the recessed square on the handle will engage with the protruding square end of the starting dog on the gear-box. *Both travel gear and rotor must be out of gear when starting.*

PREPARING FOR WORK

Before starting the engine check the oil and petrol supply. Check the oil level in the crankcase by means of the dipstick which is located on the exhaust side of the engine immediately below the governor radius arm.

Unscrew the dipstick, wipe clean, and check oil level without screwing in the threaded portion of the dipstick. The indicating marks on the dipstick indicate High and Low levels (when the thread of the dipstick is not engaged).

The engine should not be run with the oil level below the Low level as shown by the dipstick. Always top up the oil level before starting the day's work. The oil filler cap is situated on the exhaust side of the crankcase, just below the carburettor. The "Gem" Series IV being a wet sump model, the oil is carried in the engine sump.

Make certain that all the oiling points listed on the chart have received attention. See that no nuts or bolts are loose, particular attention being paid to the rotor blade bolts.

Standing on the right-hand side of the machine looking forward, flood the carburettor, and see that *both the rotor and the travel gears are in neutral*. Ensure that the throttle control lever is only just open. With the left hand lift the exhaust valve lifter. Place the starting handle into position. Briskly crank the engine and release the exhaust valve lifter after the first turn or two. When the engine starts replace the starting handle in the bracket provided on the shield.

Adjust throttle control to a brisk idling speed. See that the depth control handle is set so that the rotor is clear of the ground. Next, lift the clutch hand lever and engage the desired gear, release the clutch at the same time gently accelerating the engine.

COMMENCING CULTIVATION

Adjust the depth control lever to give the required depth of work, select the appropriate travel gear to give the required fineness of tilth, put the rotor gear in mesh and commence work keeping the engine running at a constant speed whatever type of work is being done. Do not race the engine if the work is light nor labour the engine if the work is heavy. After a little practice, no difficulty will be found in maintaining the best engine speed.

Rear Shield

To avoid an accumulation of soil choking the rotor and causing the use of unnecessary power, always keep the rear shield well raised so that the blades will throw the soil clear.

To stop the engine

Put both gears in neutral and then lift the exhaust valve lifter.

NOTES ON CULTIVATION

Since the scope of operation is so extensive, and as soil tillage methods differ so greatly with various crops, climates and soil conditions, it is only possible to deal briefly with this aspect. However, the following hints should enable the user to obtain the best results from the machine.

Virgin soil or land tightly bound together with grass or roots is best cultivated by first working shallow to break up the surface. The required depth may then be reached on successive runs over the ground.

The low gear must be used when cultivating ground that is very hard or covered with heavy growths. Second gear is used for all ordinary cultivation, and top gear for light cultivation. Always work on the highest gear that will produce the quality of tilth required. Always use top gear for running the machine between work. A depth control skid, or wheel, is fitted and by moving this up and down the depth of work is controlled in $\frac{3}{4}$ " stages from $\frac{3}{4}$ " to about 8" in depth.

When cultivating a ploughed field, the "Gem" should be run across the furrows—not along them. This will ensure complete cultivation.

On hilly ground always run the machine around the contour, working from top to the bottom of the hill. After the first cut, one road wheel can be run in the soil just cut up and any tendency to slip will be obviated by the wheel coming against a wall of uncut soil.

If the land is exceptionally light special extension rims may be supplied to prevent the machine sinking in.

Do not overtax the power of the machine—far better results will be obtained from working in easy stages rather than by forcing the machine to do work in excess of its horsepower.

NOTES FOR OPERATOR

1. The importance of regular and correct lubrication cannot be over-emphasized and particular attention must be paid to the Lubrication Chart on page 11.
2. *Air cleaner maintenance is of paramount importance. (See page 13.)*
3. The throttle must always be shut to idling position when lifting the clutch lever for engaging or disengaging gears.
4. The engine must not be allowed to idle at slow speeds for long periods.
5. Do not hold the handles firmly down if the machine jumps on striking a stump or similar obstacle, but just lightly resist the movement and let the machine right itself. This particularly applies when working on hillsides in badly cleared land.
6. When taking sharp corners, put the rotor out of gear, if necessary lifting the machine at the handles to help in turning.
7. Never run the "Gem" with the engine labouring. By selecting the right gear and the correct depth of work a reserve of engine power is always in hand.
8. When operating the "Gem," use the clutch in the same way as in a car; that is, for changing gear only. Do not "slip the clutch" to obtain extra engine speed.
9. For the first 12 hours after delivery, only light work should be done in order that the working parts are allowed to bed down properly.

LUBRICATION

(See Lubrication Chart, page 11)

ENGINE Oil must be renewed completely after every 24 hours work. The oil may require topping up from time to time and the oil level should never be allowed to fall below the Low level on the dipstick.

ROTOR DOG CLUTCH HOUSING Remove the square-headed plug [point "B" on chart], and give half a dozen spurts of oil from the oil-can. This should be done every 24 hours and particularly before starting up after any prolonged period of rest.

ROTOR DRIVE CHAIN BOX Remove the square-headed plug [point "C" on chart] on top of the chain cover and using the dipstick from the gear-box, fill the case up to the lower mark. A quarter of a pint is sufficient. Do not overfill as this may result in oil being forced on to the rotor friction clutch causing it to slip unnecessarily. This should be checked after every 24 hours of work.

ROTOR STUB AXLE [Point "D" on chart.] Remove the round-headed screw and with an oil-can, fill the oil space inside the rotor tube, every 24 hours work.

DEPTH CONTROL WHEEL Remove round-headed screw and with oil-can fill space inside the axle, every 24 hours.

GEAR-BOX Every 24 hours check the level as indicated on the uppermost mark of the dipstick, which is attached to the square-headed plug [point "E" on chart], screwed into the top of the gear-box. Normally, it should only be necessary to drain and renew the oil in the gear-box after every four hundred hours of work. Drainage is best carried out when the oil is warm and it is a good practice to remove the drain plug at the end of a day's work leaving the plug out all night. Capacity of the gear-box is approximately $\frac{3}{4}$ gallon.

In addition to these lubrication directions, points such as the slide bar of the swinging handlebars, and the fulcrum levers of the throttle and the clutch controls should be oiled with engine oil to ensure free movement.

ENGINE TROUBLE CHART

Engine fails to start

Fuel System:

- Fuel supply turned off.
- Fuel pipe choked or air lock.
- Water or dirt in fuel.
- Throttle too wide open.

Ignition System:

- Magneto contact breaker point gaps need adjustment (.012").
- Spark plug dirty or faulty
- Spark plug point gaps need adjustment. Should be .020"—.025" gap.
- Water or moisture in magneto.
- Magneto contact breaker points stuck or dirty.
- High-tension lead cracked or perished.

(continued on page 12)

LUBRICATION CHART


ENGINE Oils Recommended :

Summer

Temp. 32° - 90 :— S.A.E. 40
Temp. 90 and over :— S.A.E. 50

Winter

Temp. 10 - 32 :— S.A.E. 30



Recommended Oils :—

ROTOR DOG CLUTCH HOUSING :— S.A.E. 90
CHAIN BOX :— S.A.E. 90
ROTOR STUB AXLE :— S.A.E. 50
DEPTH CONTROL WHEEL :— S.A.E. 50
GEAR-BOX :— S.A.E. 90

Engine lacks power or runs irregularly

Fuel System:

- Fuel pipe partially blocked.
- Jets partially blocked, or not correctly adjusted.

Ignition System:

- Spark plug dirty
- Spark plug point gaps need adjustment.
- Magneto contact points dirty or need adjustment.

Mechanical Faults:

- Valve springs weak or broken.
- Cylinder head gaskets leaking.
- Valve stuck open. Valves badly burnt.
- Valve clearance incorrect. Broken piston rings.
- Badly worn piston rings and/or cylinder bore.
- Badly worn valve guides.

Engine stops suddenly

Fuel System:

- Fuel tank empty. Water in fuel.
- Overheating owing to lack of oil.
- Jet blocked by foreign matter.

Ignition System:

- Magneto contact breaker points stuck.

Engine overheats

- Ignition retarded too far.
- Spark plug dirty.

Spark plug point gaps need adjustment.

Insufficient or poor grade of oil.

Engine requires decarbonising.

Valves not seating properly.

Engine cowling blocked with grass or weeds.

Flywheel fan blocked with grass or weeds.

GENERAL MAINTENANCE

ENGINE CLUTCH The clutch is of a single fibre disc type, simple in operation and efficient in work. It should be adjusted with a little play on the lever (about $\frac{1}{4}$ " at the end) so that the thrust bearing is free except when the Hand lever is lifted. Adjustment can be made by means of the wing nut.

ROTOR FRICTION DRIVE The rotor to which the blades are bolted is driven direct from the main gear-box through a friction clutch. This clutch is not intended to operate except when the rotor blades strike an obstacle, and, when leaving the factory, is adjusted so that no slip takes place under ordinary working conditions. If it is suspected that the clutch slips

too freely, it should be adjusted by means of the four nuts; tighten up, then slack back half a turn.

ROAD WHEELS The road wheels are mounted on hubs, driven by friction clutches. These are adjusted so that the wheels have sufficient grip to pull the machine but will slip if they become jammed with an obstruction between the wheels and the frame. Adjustment as for rotor clutch.

AIR CLEANER Regular attention to this is most important. The oil level must be checked after every 8 hours running and after every 24 hours it must be dismantled and thoroughly cleaned out. To remove the cleaner, loosen the clamping screw and, leaving the cover still connected to the hose connection, take the air cleaner from its platform. Separate the top from the bottom half of the cleaner, and pour the dirty oil from the reservoir. Thoroughly wash out all sediment in the bottom with petrol. Remove the serrated spring clip in the filter container, take out the wire gauze filters and wash them in petrol. Refill the oil reservoir to the correct level with clean engine oil. Put the wire gauze filter back into the container then replace the perforated plates and the serrated spring clip. Now put the two halves together with the felt washer between and replace. Fit the cover taking care that the cover felt washer is intact and clamp back into position.

If working under exceptionally dusty conditions the air cleaner requires cleaning every 6 hours.

MAINTENANCE OF HOE BLADES It is essential that only the cutting edge should rub in the soil and that the back should have clearance.

The Blades are designed so that use in average soil tends to sharpen them, but if the machine is used on stony ground it is suggested that two sets of hoe blades should be used alternately in order that one set may be kept sharpened.

The efficiency of the machine depends largely on the condition of the hoe blades. If bent through striking solid obstacles in the ground and not straightened, they will require the power to drive, the quality of work will be poor and the blades will wear out quickly. Trouble will also be experienced with clogging under the shield. Blades should therefore be straightened up as soon as noticed with the blade setting bar which is provided for the purpose, the hooked end of which is intended to fit over the blade.

ROTOR FLANGE WEEDCUTTERS Two weedcutter blades are provided to prevent long grass or weeds from binding round the end rotor flanges. To adjust, slack the two setscrews

securing the weedcutter blade and tap the blade until it is within 1/32" of the rotor flange, revolve the rotor by hand to make sure the blade does not foul and retighten the setscrews.

ENGINE CARBURETTOR Before the engine leaves the works, the carburettor is tested and the variable jet adjusted to give the best all-round performance. If, at any time, the setting is disturbed, it will be found that one and a half turns open is a satisfactory position.

To clean the carburettor jet it is necessary to take out the main jet body (Part No. B.J.9106) through which the main jet adjusting screw operates; the idling jet is a very small hole drilled in the groove halfway up the jet bolt.

If black smoke (not blue) is emitted from the silencer when the engine is running under normal load the jet should be slowly screwed in until this stops.

If black smoke is seen when the engine is idling, the idling jet adjusting screw (Part No. B.J.9104) requires to be unscrewed slowly until this stops.

DECARBONISING THE ENGINE This will only be necessary after at least 400 hours running, and should preferably be left to the service agent who has the facilities to do the work and check the extent of cylinder, piston and valve wear.

If, however, it is essential for this work to be done on the site the following method should be followed.

Disconnect the exhaust valve lifter, throttle control, air cleaner hose, petrol pipe and exhaust. Remove the induction and exhaust manifold, sparking plugs, cowl, and valve gear cover. Slacken and remove the six cylinder holding nuts, lift the rocker assembly. The cylinder head will now lift off the block. Turn the engine until the piston is at the top of its stroke and remove the carbon deposit with a blunt knife, do not scratch the piston but thoroughly clean off any carbon. Leave a ring of carbon about 1/8" wide around the edge of the piston as this assists in maintaining an oil seal. Remove the carbon adhering to the bore *above* the piston's travel.

Next remove the valves. Carefully mark the valve heads to ensure that they are replaced in the correct positions. Place cylinder head on a bench and with two screwdrivers, compress the spring so that the split taper cotters can be removed. The valves will then withdraw. The valve heads should be cleaned with sandpaper and any carbon deposit removed from the valve pockets. Smear a small amount of *fine* grinding paste on the bevelled face of the valve and placing a broad-headed screwdriver in the slot in the head, rub the valve on its seating

with an oscillating rotary action. Do not rotate the valve continually in one direction. The valve should show a continuous bright ring all round. If any breaks or thin places show, repeat the operation. Only the minimum grinding must be given to produce this condition: a deep recessed groove in the face will impair the seating of the valve. Any burnt or deeply pitted valves should be replaced by new ones. The valve seating should show a similar continuous bright ring of uniform width. If the seat width is much over 1/16" it is necessary to have it refaced, and this should be attended to by the Service Agent at the first opportunity.

Remove all trace of grinding paste from the valve and seating by washing in petrol. Reassemble the valves, smearing a little clean oil on the valve stems.

Clean the face of the cylinder head and cylinder and replace the gasket which, if at all damaged, should be renewed. When tightening up the cylinder head bolts, tighten each an equal amount until they are all dead tight. Set tappet clearance to .008 on all tappets. Reassemble all parts in the reverse of the dismantling order. Run the engine for two or three minutes on closed throttle and re-tighten the cylinder head nuts. Take care that the engine does not overheat.

ATTACHMENTS AND EQUIPMENT

Various attachments may be used with the "GEM" Machine:—

For Mobile Work

Furrowing Attachment. Depth Control Wheel
Furrow Covering Attachment. Roller Attachment.
Picktyne Rotor. Extension Rims.
 Leaf Guards.

For Stationary Work

Power Take-off Pulley. Soil Shredder.
Waterproof Cover.

FITTING THE ATTACHMENTS

THE FURROWING ATTACHMENT is fitted on to the depth control skid. First remove the depth control skid by pivoting the depth control lever clip; pull the depth control lever sideways until the pin engaging in the skid is withdrawn and the skid may then be pulled out of the depth control socket from under the rotor shield.

Assemble the furrowing attachment on to the depth control skid leaving the bottom of the attachment approximately $\frac{1}{4}$ " above the foot of the skid, or as required for the crop to be planted, and tighten locking nut. Fit the assembly in the depth control socket and connect to depth control lever. For machines where a depth control wheel has been fitted in place of a skid, the skid must also be ordered in addition to the furrowing attachment. When using the furrower, the rotor is put in gear so that the combined operations of cultivating and furrowing are carried out simultaneously.

THE FURROW COVERING ATTACHMENT is fitted into the depth control socket in the same way as the furrower, except that it is supplied with its own pedestal. When in use, the rotor should be out of gear and allowed to roll over the ground like a wheel.

THE ROLLER ATTACHMENT is used in place of the depth control wheel or skid, and is intended to consolidate the land. The roller may be loaded with sand to increase its weight and will

leave a smooth surface ready for drilling or planting. This attachment is used in conjunction with the rotor.

Depth for the above operations is controlled in the same way as for ordinary cultivation.

ROAD WHEEL EXTENSION RIMS can be supplied when the machine has a tendency to sink in very light lands, and to prevent side slip when working on steep contours. They are bolted by five bolts to holes provided in the existing road wheels (cleated type only). The road wheel extension flange can be supplied with or without serrations (the illustration in the Parts List shows the serrated type). Alternatively, the flange may be removed to leave a plain extension rim only. An extended starting handle is required with these rims and is supplied with all orders for rims.

THE PICKTYNE ROTOR which is used for special work such as dealing with very hard soil conditions or for pasture renovation is fitted as follows:—

Slack off all nuts and bolts holding the support bracket carrying the stub axle, staytube and rotor shield. Remove the four rotor friction drive adjusting nuts and springs. Spring the bracket off the stub axle with bar and slide the rotor sideways and withdraw. The Picktyne rotor is fitted by reversing the operations above. Unless otherwise stated, the Picktyne rotor is supplied complete with Picktynes, bolts and nuts and stub axle assembly.

To fit the **POWER TAKE-OFF**:—Remove the hinge bolt for the starting handle, remove the four set screws holding the starting dog bearing cover in place on the gear-box side-plate and remove the cover and loose dog. Assemble power take-off casting in place of the bearing cover, and ensure that the dogs in the bearing and power take-off mesh before replacing the four set screws. Next insert a long bolt in the hole provided in the power take-off casting and tighten. After oiling the power take-off bearing behind the pulley it is ready for use.

To fit the **SOIL SHREDDER**:—Remove depth control skid or wheel and one end rotor blade on the right-hand flange and replace by feeder blade. Lift the back of the machine sufficiently high to pass the shredder into position under the rotor, lower the machine ensuring that the lugs on the shredder locate the staytube and chain case and tighten the clamping bolts.

A **WATERPROOF CANVAS COVER** can be supplied for covering the "Gem" when not in use.

SPARE PARTS LIST

AND

DIAGRAMS

ORDERING SPARE PARTS

IMPORTANT. When ordering spare parts always give part number and name and quote the serial number of your machine which is stamped on the main frame member at the rear of the fuel tank. In the case of engine parts the number of the engine should be also quoted. This information will ensure correct parts being sent.

All reference to left and right hand are to be read as from rear of machine looking forward.

When ordering a new part it should be located from the Parts Diagrams, on following pages and the part number noted. Refer to the Parts Lists and obtain the correct name of the part.

The following parts are supplied assembled:—

25021 Bull wheel supplied complete with differential pinion studs 25024.

25028 Differential plate supplied complete with differential pinion studs 25024.

25286 Fly wheel supplied complete with driving pins B.J.8002.


It is also recommended that:—

Crown wheel and pinion be paired.

Road wheel shaft be supplied assembled with fixed hub gear.

Illust. No.	Part No.	Description	No. off
CRANKCASE AND CYLINDER (Plate 1)			
1	25604	Bumper bar ...	1
2	25691	Timing case ...	1
3	25192	Timing case cover gasket ...	1
4	25195	Crankcase end plate ...	1
5	25714	Tab washer ...	1
6A		Countersunk screw $\frac{3}{8}$ " B.S.F. X $\frac{3}{8}$ " L.	3
6B		Setscrews Hex. Hd. $\frac{1}{8}$ " B.S.F. X $\frac{1}{8}$ " L.	1
6C		Setscrews Hex. Hd. $\frac{1}{8}$ " B.S.F. X $\frac{1}{8}$ " L.	1
6D		Setscrews Hex. Hd. $\frac{1}{8}$ " B.S.F. X $\frac{1}{8}$ " L.	4
—	6E	Spring washers $\frac{3}{8}$ " dia.	8
—	6F	Setscrews Hex. Hd. $\frac{1}{8}$ " B.S.F. X $\frac{1}{8}$ " L.	4
—	6H	Setscrews securing magneto $\frac{1}{8}$ " B.S.F. X $\frac{7}{16}$ " L.	4
7		Spring washers $\frac{1}{2}$ " dia.	4
8	25196	Crankcase end plate gasket	1
9	25257	Dipstick ...	1
10	25414	Dipstick washer ...	1
11	25243	Filler plug ...	1
12	25244	Filler plug washer ...	1
13	25186	Circlip—Internal 3" dia.	1
14	25189	Crankcase sump gasket ...	2
15	25334	Scoop trough ...	2
16	25335	Locking wire ...	2
17	25127	Crankcase sump ...	2
18	25258	Sump drain plug ...	2
19	25259	Sump drain plug washer ...	2
20		Bolt, Sump, Corners Hx. Hd. $\frac{1}{2}$ " B.S.F. X $1\frac{3}{4}$ " L.	4
21		Bolt, Sump intermediate Hx. Hd. $\frac{1}{2}$ " B.S.F. X $2\frac{1}{2}$ " L.	6
22	25256	Spring washers $\frac{1}{2}$ " dia.	10
23	25129	Flywheel fan housing gasket	1
24		Flywheel fan housing	1
25	25592	Setscrew Hex. Hd. $\frac{3}{8}$ " B.S.F. X $\frac{3}{8}$ " L.	6
26	25591/1	Spring washer $\frac{3}{8}$ " dia.	1
27	25591/2	Cowling, base plate	1
28	25591/4	Cowling, rear half ...	1
29		Cowling, front half ...	1
30		Cowling, hinge pin ...	1
31		Setscrew securing rear cowling $\frac{1}{2}$ " B.S.W. X $\frac{1}{2}$ " L.	6
32		Spring washer $\frac{1}{2}$ " dia.	6
33		Nut $\frac{1}{2}$ " B.S.W.	3
34	25593	Magneto lead clip ...	1
35	25695	Captive bolt securing front cowling	1
36	25694	Wing nut $\frac{1}{2}$ " B.S.F. ...	1
37	25408	Spark plug cover and terminal	2
38	25343	Spark plug (14 mm. long reach)	2
39	25344	Spark plug washer ...	2
40	25270	Cylinder block assembly ...	1
41	25180	Cylinder block gasket	1
42	25272	Cylinder block stud, short	3
43	25338	Cylinder block stud, medium	1
44	25271	Cylinder block stud, long	2
45		Nut $\frac{3}{8}$ " B.S.F.	6
46		Spring washer $\frac{3}{8}$ " dia.	6
47		Cylinder head gasket	1

PLATE I




CRANKCASE AND CYLINDER ASSEMBLY

Illust. No.	Part No.	Description	No. off
44	25188	Cylinder head	1
45	25300	Rocker shaft end bearing	2
46	25301	Rocker shaft centre bearing	1
47		Centre bearing set screw $\frac{1}{8}$ " B.S.F. X $\frac{1}{4}$ " L.	1
48	25238	Spring washer $\frac{1}{8}$ " dia.	2
49		Manifold stud	2
50		Spring washer $\frac{1}{8}$ " dia.	2
51		Nut $\frac{1}{8}$ " B.S.F.	2
52	25276	Manifold gasket	1
53	25228	Combined inlet and exhaust manifold	1
54	25649	Exhaust muffler gasket	1
55	25311	Exhaust muffler assembly	1
56		Setscrew $\frac{1}{8}$ " B.S.W. X $\frac{1}{4}$ " L.	2
57	25339	Spring washer $\frac{1}{8}$ " dia.	2
58	25280	Cylinder head cover	1
59	25694	Cylinder head cover gasket	1
60	25578	Wing nut $\frac{1}{8}$ " B.S.F.	2
61	8390	Fibre washer	2
62		Breather valve body plug	1
63	1394	Fibre washer	1
64	8411	Breather valve ball	1
65	8380	Breather valve body	1
66	8420	Spring	1
67	1396	Fibre washers	2
68	8400	Breather pipe assembly	1
69		68-69 spare	1
70	25197	Magneto flange	1
71	25255	Magneto flange gasket	1
72		Magneto (complete)	1
73		(For Magneto Spare Parts see Illustration Nos. 801-870 below)	1
74	25583	Exhaust valve lifting cam	2
75	25594	Sleeve	2
76	25585	Nut	2
77	25586	Fibre washer	2
78	25590	Return spring	1
79	25716	Washer	2
80	25580	Long lever	1
81	25581	Short lever	1
82	25587	Mills pin	1
83	25582	Connecting link	2
84	25715	Trunnion	1
85	25646	Control rod	1
86		Split pin $\frac{1}{16}$ " dia. X $\frac{1}{2}$ " L.	2
87		86-87 spare	1
88	25299	Rocker shaft	1
89	25303	Spacer tube, long	2
90	25304	Spacer tube, short	2
91	25302	Rocker shaft spring	2
92	25297	Rocker lever, inlet and exhaust	4
93	25298	Rocker lever adjusting screw	4
94		Locknut $\frac{1}{8}$ " B.S.F.	4
95		94-95 spare	4

DECOMPRESSOR CONTROL (Plate 2)

VALVE AND CAMSHAFT (Plate 2)

PLATE 2



Illust. No.	Part No.	Description	No. off
96	25203	Valve	4
97	25209	Valve guide	4
98	25239	Split collet	4
99	25249	Collar	4
100	25275	Valve spring	4
101	25202	Push rod	4
102	25237	Tappet	4
105	25190	Cam shaft	1
106	25307	Key	1
107	25204	Timing pinion, camshaft	1
108		Slotted nut $\frac{3}{8}$ " B.S.F.	1
109		Washer $\frac{3}{8}$ " dia. plain	1
110	25199	Split pin $\frac{3}{8}$ " dia. X $1\frac{1}{2}$ " L. Magneto pinion	1
CRANKSHAFT (Plate 2)			
111	25194	Timing pinion, crankshaft	1
112		Slotted nut $\frac{3}{8}$ " B.S.F.	1
113		Washer $\frac{3}{8}$ " dia. plain	1
114	25125	Split pin $\frac{3}{8}$ " dia. X $1\frac{1}{2}$ " L.	1
115	25288	Crankshaft	2
116	BRL. 1 $\frac{1}{8}$	Woodruff key $3" \times 1\frac{1}{8}" \times 1\frac{1}{8}"$ W.	1
117	25285	Ball bearing $2\frac{1}{8}" \times 1\frac{1}{8}" \times \frac{3}{8}"$ W.	1
118		Oil seal $2\frac{1}{8}" \times 1\frac{1}{8}" \times \frac{3}{8}"$ W.	1
119		Flywheel assembly (with clutch pins)	1
120	25286	Flywheel clutch pin	6
121	25246	Flywheel nut (see below for assembly)	1
122	25187	Flywheel nut (see below for assembly)	1
123	BRL. $\frac{1}{8}$	Ball bearing $1\frac{1}{8}" \times \frac{1}{2}" \times \frac{3}{8}"$ W.	1
124	BJ.8007	Bearing retainer washer	1
125		Flywheel nut complete assembly	1
126	25287	Flywheel nut complete assembly	1
CONNECTING ROD AND PISTON (Plate 2)			
127	25124	Connecting rod (top and bottom parts)	1
128	25216	Half bearing, top	2
129	25217	Half bearing, bottom	2
130	25251	Bolt	4
131	25333	Locking wire	2
132	25242	Gudgeon pin bearing	2
133	25291	Gudgeon pin	4
134	25292	Gudgeon pin circlip	4
135	25122	Piston	2
136	25293	Piston ring, plain	4
137	25294	Piston ring, scraper	2
138		Governor pinion (see below for assembly)	1
139		Governor weight	2
140	25220	Governor weight	2
141	25253	Governor weight pin	2
142	25254	Governor pinion and weight riveted assembly	1
143	25308	Thrust plate	1
144	25225	Governor sleeve	1
145	25229	Grub screw $\frac{3}{8}" \times \frac{1}{2}"$ L.	1
146	25354	Ball bearing $1\frac{1}{8}" \times \frac{1}{2}" \times \frac{3}{8}"$ W.	3

CRANKSHAFT ASSEMBLY

146		Circlip external $\frac{1}{8}$ " dia.	...
147	25240	Adjusting nut	...
148	25230	Split pin $\frac{1}{8}$ " dia. X $1\frac{1}{2}$ " L.	...
149	25579	Spindle	...
150	25245	Collar	...
151	25247	Spring	...
152	25248	Trunnion	...
153	25409	Cranked spindle	...
154	25317	Sealing ring	...
155-157	spare	Sleeve	...
158	25594	Lever	...
159	25713	Key ... $\frac{1}{8}$ " B.S.F. X $\frac{1}{2}$ " L.	...
160		Trunnion	...
161	G.789	Split pin $\frac{1}{8}$ " dia. X $\frac{3}{4}$ " L.	...
162	25601	Throttle control rod from frame arm	...
163	25600	Throttle control rod from governor to carb.	...
164	25603	Spring	...

AIR CLEANER (Plate 3)

201	G.178	Inlet pipe cap	...
202	G.180	Gauze container	...
203	G.181	Tank cover	...
204	G.182	Gauze container clip	...
205	G.185	Tank
206			...
207	G.269	Tank gasket
208	G.270	Cover gasket	...
209	G.271	Perforated plate	...
210	G.272	Perforated cone	...
211	G.273	Gauze filter	...
212	G.274A	Hose connection to carburettor	...
213	J.9530	Hose clips	...
214	G.276	Hose clips	...

CARBURETTOR (Plate 3)

BJ.8098		Carburettor, complete assembly	...
215-217	spare		...
218	BJ.9100	Carburettor body	...
219	BJ.9101	Throttle lever, spindle and stop	...
220	BJ.9102	Throttle stop screw	...
221	BJ.9104	Air adjusting screw	...
222	BJ.9135	Locknuts	...
223	BJ.9105	Throttle valve	...
224	BJ.9106	Adjustable main jet body	...
225	BJ.9107	Needle for main jet	...
226	BJ.9134	Locknut	...
227	BJ.9108	Washer for float chamber union	...
228	BJ.9110	Plug screws for mixing chamber	...
229	BJ.9111	Gland washer	...
230	BJ.9112	Cork gland	...
231	BJ.9113	Gland adjusting screw	...
232	BJ.9114	Outlet pipe clip	...
233	BJ.9115	Outlet pipe clip pin	...
234	BJ.9116	Throttle valve screw	...
235	BJ.9117	Locking washers	...
BJ.9118		Float chamber complete assembly	...

AIR CLEANER and CARBURETTOR





PLATE 3

PLATE 4




GEAR - BOX

Illust. No.	Part No.	Description	No. off
236	BJ.9119	Float chamber only	1
237	BJ.9120	Float chamber cover	1
238	BJ.9121	Cover lock screw	1
239	BJ.9122	Float	1
240	BJ.9123	Needle	1
241	BJ.9124	Tickler	1
242	BJ.9136	Tickler stop	1
243	BJ.9126	Tickler spring	1
244	BJ.9127	Tickler cotter pin	1
245	BJ.9128	Plug screw	1
246	BJ.9129	Plug screw washer	1
247	BJ.9130	Needle seat lock nut	1
248	BJ.9131	Needle seat lock nut	1
249	G.229	Petrol pipe union nut	1
250	G.227	Petrol pipe union nipple	1
251-299	spare		
GEAR-BOX CASING (Plates 4 & 5)			
300	25048	Casing	1
301	G.476	Dipstick	1
302	25121	Inspection cover	1
303	25185	Inspection cover gasket	1
304		Setscrew $\frac{1}{4}$ " B.S.W. Rd. Hd. $\times \frac{3}{8}$ " L.	4
305		Spring washer $\frac{1}{4}$ " dia.	8
306	G.479	Flywheel housing bolt $\frac{1}{4}$ " B.S.W. $\times \frac{1}{2}$ " L.	1
307	25049	Drain plug	1
308	25050	Gear-box cover	1
309		Cover gasket	1
310	25059	Cover setscrews $\frac{5}{16}$ " B.S.W. $\times \frac{1}{4}$ " L.	15
311	G.374	Spring washers $\frac{5}{16}$ " dia.	15
312		Mills pin	2
313		Starting dog bearing housing	1
314	G.402	Setscrew $\frac{3}{8}$ " B.S.W. $\times \frac{3}{4}$ " L.	4
315	G.373	Spring washer $\frac{3}{8}$ " dia.	4
316	G.437	Starting dog bearing housing gasket	1
317		Starting dog	1
318	G.436	Starting dog bearing	1
319	25006	Jackshaft	1
320	25074	Reverse selector	1
321	25072	Reverse selector block	1
322	25005	Split pin $\frac{1}{8}$ " dia. $\times \frac{3}{4}$ " L.	1
323	25115	Double pinion	1
324	G.481	Speed change selector assembly	2
325	25029	Selector bush	1
326	25008	Jackshaft	1
327	G.451	Crownwheel	6
328	G.461	Rivets $\frac{5}{16}$ " dia. $\times \frac{3}{4}$ " L. Rd. Hd.	1
329	25065	Ball bearing	1
330	25063	Jackshaft shim	1
331	25064	Spring lubricating belt	1
332		Lubricating belt wheel	1
333		Pin	1
334		Slotted nut $\frac{3}{8}$ " B.S.F.	1
335		Split pin $\frac{1}{8}$ " dia. $\times \frac{1}{2}$ " L.	1
JACKSHAFT (Plates 4 & 5)			
336	G.436	Circlip	1
337	25006	Single pinion	1
338	25074	Reverse selector	1
339	25072	Reverse selector block	1
340	25005	Split pin $\frac{1}{8}$ " dia. $\times \frac{3}{4}$ " L.	1
341	25115	Double pinion	1
342	G.481	Speed change selector assembly	2
343	25029	Selector bush	1
344	25008	Jackshaft	1
345	G.451	Crownwheel	6
346	G.461	Rivets $\frac{5}{16}$ " dia. $\times \frac{3}{4}$ " L. Rd. Hd.	1
347	25065	Ball bearing	1
348	25063	Jackshaft shim	1
349	25064	Spring lubricating belt	1
350		Lubricating belt wheel	1
351		Pin	1
352		Slotted nut $\frac{3}{8}$ " B.S.F.	1
353		Split pin $\frac{1}{8}$ " dia. $\times \frac{1}{2}$ " L.	1

PLATE 5

Illust. No.	Part No.	Description	No. off
LAYSHAFT (Plates 4 & 5)			
335	G. 354	Bearing stop	1
336	G. 355	Gasket	1
337		Setscrew $\frac{1}{8}$ " B.S.W. X $\frac{3}{8}$ " L.	3
		Spring washer $\frac{1}{8}$ " dia.	3
		Shim	As req.
338	25054	Ball bearing	1
339	G. 353	Layshaft	1
340	25037	Large gear	1
341	25011	Medium gear	1
342	25012	Spacer	1
343	25015	Small gear	1
344	25013	Bull pinion	1
345	25025	Ball bearing $2\frac{1}{4}$ " X $1\frac{1}{2}$ " X $\frac{3}{8}$ " w	1
346	BLR1	Special nut	1
347	25038	Split pin $\frac{3}{32}$ " dia. X $2\frac{1}{2}$ " L.	1
348		Reverse idler gears	1
349	25027	Reverse idler gears	1
350	25034	Reverse idler gears	1
351	25026	Reverse idler gears bush	1
352		Washer $\frac{3}{8}$ " dia.	1
		Slotted nut $\frac{3}{8}$ " B.S.W.	1
		Split pin $\frac{3}{32}$ " dia. X $1\frac{1}{4}$ " L.	1
ROADWHEEL SHAFT (Plates 4 & 5)			
353	25051	Wheelhub, right	1
354	G. 162	Wheelhub disc (both wheels)	2
	25393	Studs, long } 30" machine	4
	25394	Studs, short }	8
355	G. 141	Studs (both wheels) 24" machine	8
356	G. 142	Springs (both wheels)	8
357		Washers (both wheels) $\frac{3}{8}$ " dia.	8
358		Nuts (both wheels) $\frac{3}{8}$ " B.S.W.	8
359	25351	Hub nut, right	1
360		Oil seal	1
361	G. 305	Ball bearing $3\frac{1}{2}$ " X $1\frac{3}{4}$ " X $\frac{1}{8}$ " W.	1
362	BRE.14	Differential plate	1
363	25028	Differential pinion pins	3
364	25023	Loose hub gear	1
365	25020	Differential pinions	6
366	25022	Fixed hub gear	3
367	25019	Pinion studs	3
368	25021	Special nut	3
369	25042	Split pin $\frac{3}{32}$ " dia. X $1\frac{3}{4}$ " L.	3
370	25021	Bull wheel	1
371	25046	Road wheel axle	1
372		Rivet $\frac{1}{4}$ " dia. X $1\frac{1}{4}$ " L. Rd. Hd.	6
373		Differential lock selector	1
374	25359	Differential lock	1
375	G. 313	Differential lock ring	1
376	G. 314	Differential lock pin	3
377	25056	Differential lock setscrew	3
378	G. 317	Differential lock spacer	1
379	G. 316	Ball bearing $2\frac{1}{4}$ " X $1\frac{1}{4}$ " X $\frac{1}{8}$ " w.	1
380	BRL.14	Oil seal disc	1
381	25058	Oil seal $2\frac{1}{2}$ " X $1\frac{1}{4}$ " X $\frac{1}{8}$ "	1
382		Wheel hub, left	1
383			
384	25052		



GEAR - BOX

Illust. No.	Part No.	Description	No. off
-------------	----------	-------------	---------

385		Hub washer, $\frac{1}{4}$ " dia.	1
386	25047	Hub nut	1
387	25053	Split pin $\frac{3}{8}$ " dia. X 2" L.	1
388	25057	Axle bearing stop	1
389		Axle bearing stop gasket	4
		Setscrew $\frac{3}{8}$ " B.S.W. X $\frac{3}{8}$ " L.	4
		Spring washer $\frac{3}{8}$ " dia.	4

ENGINE CLUTCH (Plate 4)

390	G.220	Friction disc	1
391	G.230	Loose plate	1
392	25071	Fixed plate	1
393	G.290	Thrust plate with driving pin	1
	G.234	Thrust plate driving pin only	3
394	G.260	Spring	3
395	G.255	Distance piece	3
396	G.250	Bolt	3
397		Shaft	1
398	25009	Thrust race $\frac{3}{4}$ " bore	1
399	SFL $\frac{1}{2}$	Operating pawl	1
400	G.291	Thrust sleeve	1
401	G.288	Shaft oil seal	1
402	25069	Shaft oil seal	1
403		Shaft $\frac{1}{2}$ " B.S.W. X $\frac{3}{4}$ " L. Rd. Hd.	3
		Spring washer $\frac{3}{8}$ " dia.	3
404	25007	Spiral bevel pinion	1
405	25061	Special nut	1
		Split pin $\frac{3}{8}$ " dia. X 1 $\frac{1}{4}$ " L.	1
406	BRM. $\frac{3}{4}$	Ball race $2 \frac{1}{2}$ " X $\frac{1}{4}$ " X $1 \frac{1}{8}$ " W.	1
407		Circlip	1
408	25062	Special nut	1
		Split pin	1

JACKSHAFT EXTENSION (Plate 6)

410	25735	Housing (30" machine)	1
410	25470	Housing (24" machine)	1
411	G.454	Housing studs	2
		Spring washers $\frac{3}{8}$ " dia.	2
412		Nuts $\frac{3}{8}$ " B.S.W.	2
413		Setscrews $\frac{3}{8}$ " B.S.W. X 1" L.	2
		Spring washers $\frac{3}{8}$ " dia.	2
414	G.402	Gasket	1
415	G.439	Sliding dog	1
416	G.156	Selector block	1
417	G.157	Selector cotter pin	1
418	G.153	Selector	1
419	G.456	Dog clutch housing cover	1
420	G.458	Oil plug	1
421		Shaft $\frac{1}{2}$ " B.S.W. X $\frac{3}{4}$ " L.	2
		Spring washers $\frac{1}{8}$ " dia.	2
422		Rivets $\frac{1}{4}$ " dia. X $\frac{3}{8}$ " L. Rd. Hd.	8

CHAINCASE (Plate 6)

423	G.530	Chaincase back plate	1
424		Setscrew, back plate to shield $\frac{1}{4}$ " B.S.W. X $\frac{1}{2}$ " L. Rd. Hd.	1
		Spring washer $\frac{1}{4}$ " dia.	1
		Nut $\frac{1}{4}$ " B.S.W.	1
425	591	Frame setscrew, countersunk head	1
426			1

JACKSHAFT EXTENSION, CHAINCASE AND ROTOR




PLATE 6

Illust. No.	Part No.	Description	No. off
JACKSHAFT EXTENSION (Plate 6)			
427	G.452/2	Fixed dog	1
428	G.452/3	Fixed dog rivet	1
429	25738	Shaft (30" machine)	6
429	25468	Shaft (24" machine)	6
430	BRM.1	Ball bearing 2 1/2" x 1" x 1 1/4" W.	8
431	G.462	Shim	As req.
432	G.460	Sprocket	24
ROTOR (Plate 6)			
466	25734	Rotor (30" machine)	1
466	25462	Rotor (24" machine)	1
467	G.900R	Hoe blade, right	6
468	G.900L	Hoe blade, left	6
469	G.919	Blade bolts (end flanges)	8
470	G.918	Blade bolt (intermediate flanges)	16
—	G.920	Blade spring washers	24
—	—	Blade nuts 3/16" B.S.F.	24
ROTOR STUB AXLE (Plate 6)			
471	G.635	Back plug	1
472	—	Oiling screw 1/4" B.S.W. x 3/8" L. Rd. Hd.	1
473	G.639	Inner dust cover	1
474	—	Inner dust cover rivets 3/16" dia. x 1/2" L. Rd. Hd.	3
475	—	Stub axle	1
476	G.630	Ball bearing 1 1/4" x 3/8" x 3/8" W.	1
477	BRM. 3/8	Oil seal 1 1/2" x 1/2" x 3/16" W.	1
478	—	Oil seal holder	1
479	G.637	Spacing sleeve	1
480	G.634	Felt dust seal	1
481	G.629	Bearing cap	1
482	G.632	Outer dust cover	1
483	G.640	Washer	1
484	G.648	Nut 3/8" B.S.F. locknut	1
485	—	Stub axle	1
486	G.630	Ball bearing 1 1/4" x 3/8" x 3/8" W.	1
FRAME (Plate 7)			
487	24G.993	Rotor blade setting bar { 24" machine	1
488	30G.993	Rotor blade setting bar { 30" machine	1
—	25322	Main frames { 24" machine	1
—	25730	Main frames { 30" machine	1
HANDLEBARS (Plate 7)			
489	G.104	Pivot block	1
490	—	Slotted nut 3/8" B.S.F.	1
491	—	Split pin 1/2" dia. x 1 1/2" L.	1
492	—	Pivot bolt 1/2" B.S.W. x 2 1/2" L.	1
493	—	Locknut 1/2" B.S.W.	1
494	G.122	Handlebars	2
495	G.123	Grips	2
—	—	Slide	1
—	—	Bolts 3/8" B.S.W. x 1 1/4" L.	2
—	—	Spring washers 3/8" dia.	2
—	—	Nuts 3/8" B.S.W.	2
496	—	Slide clamp bolts	2
497	25392	Spring washers 3/8" dia.	2
—	—	Nuts 3/8" B.S.W.	2
DEPTH CONTROL (Plate 7)			
498	—	Socket bolts 3/8" B.S.W. x 2 1/2" L.	2
499	25219	Nuts 3/8" B.S.W.	2
500	G.950	Socket	1
—	—	Skid 24" model only	1
501	G.671	Arm (Depth control wheel for 30" model see Plate 5)	1

Illust. No.	Part No.	Description	No. off
JACKSHAFT EXTENSION (Plate 6)			
433	25101	Drive chain complete	1
434	25101/2	Chain connecting link (quote make of chain)	1
435	G.523	Sprocket nut	1
436	G.520	Split pin 3/8" dia. x 1 1/2" L.	1
437	G.522	Chaincase gasket	1
438	G.519	Chaincase	1
439	—	Oil filler plug	1
440A	—	Wearing shoe	1
440B	—	Setscrew 1/4" B.S.W. x 3/8" L. Rd. Hd.	1
440C	—	Setscrew 1/4" B.S.W. x 1/2" L. Rd. Hd.	6
440D	—	Setscrew 1/4" B.S.W. x 3/8" L. Rd. Hd.	2
440E	—	Setscrew 1/4" B.S.W. x 1/2" L. Rd. Hd.	7
—	—	Setscrew 1/4" B.S.W. x 1/2" L. Hx. Hd.	17
—	—	Spring washers 1/4" dia.	10
—	—	Nuts, on 440C, D & E 1/4" B.S.W.	10
441	G.590	Setscrew, chain box to stay tube	1
442	G.585	Chain skid	1
443	—	Chain skid locking screw 1/8" B.S.W. x 3/4" L.	1
—	—	Washer 3/16" dia.	1
—	—	Nut 1/8" B.S.W.	1
444	—	Chain skid hinge bolt 1/8" B.S.W. x 1 1/4" L.	1
—	—	Washer 3/16" dia.	1
—	—	Nut 1/8" B.S.W.	1
ROTOR DRIVE (Plate 6)			
445	G.560	Drive sprocket	1
446	G.550	Drive shaft	1
447	—	Sprocket rivets 1/4" dia. c'sk x 3/8" L.	6
448	G.554	Sprocket shim	As req.
449	BRM.030	Ball bearing 72 mm. x 30 mm. x 19 mm. W.	1
450	—	Oil seal 2 1/2" x 1 1/2" x 1/2" W.	1
451	G.552	Spacing sleeve	1
452	G.545	Dust cover	1
453	—	Bearing housing rivets 1/4" dia. Rd. Hd. x 3/4" L.	8
454	G.540	Drive shaft bearing housing	1
455	—	Drive shaft bearing housing	1
ROTOR SAFETY CLUTCH (Plate 6)			
456	G.605	Drive plate	1
457	G.607	Ferodo fibre rings	2
458	G.606	Drive disc	1
459	G.544	Wearing plate	1
460	G.1369	Drive shaft washer	1
461	—	Drive shaft nut 3/4" B.S.F. slotted	1
—	—	Split pin 3/8" dia. x 1 1/2" L.	4
462	G.603	Studs	4
463	G.602	Springs	4
464	—	Nuts	4

Illust. No.	Part No.	Description	No. off
502		Pivot bolts $\frac{3}{8}$ " B.S.W. X $1\frac{1}{2}$ " L.	...
		Thackeray washer $\frac{3}{8}$ " dia.
		Washer $\frac{3}{8}$ " dia.
		Nut $\frac{3}{8}$ " dia.
503	G.674	Arm clip
504	G.675	Arm clip spring
505		Arm clip bolt $\frac{1}{2}$ " B.S.W. X $1\frac{1}{2}$ " L.	...
506		Nut $\frac{1}{2}$ " B.S.W.
FRAME (Plate 7)			
507	G.667	Support stay, right
508	G.668	Support stay, left
509		Bolt, support stay to socket $\frac{1}{4}$ " B.S.W. X $1\frac{1}{2}$ " L.	...
		Spring washers $\frac{1}{4}$ " dia.
		Nut $\frac{1}{2}$ " B.S.W.
510		Crossmember bolts $\frac{1}{2}$ " B.S.W. X $1\frac{1}{4}$ " L.	3
		Spring washers $\frac{1}{2}$ " dia. ...	3
		Nuts $\frac{1}{2}$ " B.S.W. ...	3
511	G.790	Tool box
512	G.650	Side frame
513	G.591	Setscrew, countersunk head
514	G.821	Weed cutter blade, right ...	2
515	G.820	Weed cutter blade, left ...	2
516	G.830	Keeper plate ...	4
517		Setscrew $\frac{1}{2}$ " B.S.W. X $\frac{1}{2}$ " L.	4
		Spring washers $\frac{1}{2}$ " dia. ...	4
518		Weed cutter bracket ...	1
519	G.825	Weed cutter bracket ...	1
SHIELD (Plate 7)			
520		Rear shield hinge bolts $\frac{3}{8}$ " B.S.W. X $1\frac{1}{2}$ " L.	2
		Spring washers $\frac{3}{8}$ " dia. ...	2
521	G.644	Rear shield champing bolts ...	2
		Washers $\frac{3}{8}$ " dia. ...	2
		Simmonds nut $\frac{3}{8}$ " B.S.W., thick ...	2
522	25436	Front shield { 24" machine	1
	25743	{ 30" machine	1
523	25443	Rear shield { 24" machine	1
	25744	{ 30" machine	1
524	25454	Trailing board { 24" machine	1
	25746	{ 30" machine	1
525	25479	Trailing board, hinge bar { 24" machine	1
	25751	{ 30" machine	1
526	G.647	Hinge lock nuts $\frac{3}{16}$ " B.S.W. ...	2
527		Hinge bracket ...	2
528		Bracket rivets $\frac{3}{8}$ " dia. Rd. Hd. X $\frac{1}{2}$ " L. ...	4
530		Setscrews, side frame $\frac{1}{2}$ " B.S.W. Rd. Hd. X $\frac{3}{8}$ " L.	3
531		Setscrews, side frame $\frac{1}{2}$ " B.S.W. Rd. Hd. X $\frac{3}{8}$ " L.	3
		Spring washers $\frac{1}{2}$ " dia. ...	5
		Nuts $\frac{1}{2}$ " dia. ...	5
FRAME (Plate 7)			
532	25428	Staytube { 24" machine	1
	25747	{ 30" machine	1
533	G.381	Starting handle support lug ...	1
534		Setscrew lug to staytube $\frac{3}{8}$ " B.S.W. X $\frac{1}{2}$ " L.	1
		Spring washer $\frac{3}{8}$ " dia. ...	1
535	25466	Starting handle and block { 24" machine	1
	25561	{ 30" machine	1
(See also Road wheel ext. Plate 9)			




PLATE 7

536	G.382	Bolt starting handle block to frame	1
537		Nut $\frac{1}{8}$ " B.S.W.	1
		Setscrews, staytube to gear-box $\frac{3}{8}$ " B.S.W. X $1\frac{1}{2}$ " L.	4
		Spring washers $\frac{3}{8}$ " dia.	4
538		Setscrews, main frame to gear-box $\frac{3}{8}$ " B.S.W. X $\frac{3}{4}$ " L.	5
		Spring washers $\frac{3}{8}$ " dia.	5
539		Throttle rod hook bolt	1
540	G.708	Spring washer $\frac{1}{2}$ " dia.	1
		Nut $\frac{1}{4}$ " B.S.W.	1
541	G.183	Air cleaner clamp screw	1

FUEL TANK (Plate 7)

542	25376	Tank assembly complete with cap	1
543	G.175	Tank straps	2
		Spring washers $\frac{1}{2}$ " dia.	4
		Nuts $\frac{1}{4}$ " B.S.W.	4
	544-548 spare	Petrol filter core	1
549	G.171	Petrol filter drain plug	1
550	25413	Petrol filter drain fibre washer $\frac{3}{8}$ " dia.	1
551	G.166	Petrol supply cock	1
552	25376	Petrol pipe	1

WHEELS (Plate 7)

553	G.130	Land wheel	2
554-557	spare	Pneumatic wheel, left	1
558	G.131	Pneumatic wheel, right	1
559	G.132	Inner tube	2
560	G.133	*Outer cover	2
	G.134	(*2 each additional for double wheels, see "extension hubs")	2

THROTTLE CONTROL (Plate 8)

561-575	spare	Hand lever	1
576	797	Lever fulcrum bolt $\frac{1}{4}$ " B.S.W. X $\frac{3}{4}$ " L.	1
577		Locknut $\frac{1}{4}$ " B.S.W.	1
578	G.795	Control rod, hand lever to frame arm	1
579	G.789	Split pin $\frac{1}{8}$ " dia. X $\frac{1}{2}$ " L.	1
		Trunnion	1
		Split pin $\frac{3}{16}$ " dia. X $\frac{1}{2}$ " L.	1
580	G.799	Frame arm	1
581		Arm pivot bolt $\frac{1}{4}$ " B.S.W. X $\frac{1}{8}$ " L.	1
		Thackeray washer $\frac{1}{4}$ " dia.	1
		Locknut $\frac{1}{4}$ " B.S.W.	1
582	25601	Throttle control rod	1
583		Split pin $\frac{3}{16}$ " dia. X $\frac{1}{2}$ " L.	1

TRAVEL GEAR CONTROL (Plate 8)

584	25154	Gear lever handle	1
585	25161	Spring	1
586	25158	Gear lever	1
587	25173	Gate	1
588		Fulcrum bolt $\frac{1}{4}$ " B.S.W. X $\frac{3}{4}$ " L.	1
		Washer $\frac{1}{4}$ " dia.	1




PLATE 8

Illust. No.	Part No.	Description	No. off
589	25136	Locknut $\frac{1}{4}$ " B.S.W. ...	1
590		Rear support bracket ...	1
591		Nut $\frac{1}{8}$ " B.S.W. ...	1
591	25415	Washer $\frac{1}{16}$ " dia. ...	1
592		Trunnion $\frac{1}{8}$ " dia. ...	1
592		Washer $\frac{1}{16}$ " dia. ...	1
592		Slotted nut $\frac{1}{8}$ " B.S.W. ...	1
593	25139	Split pin $\frac{3}{32}$ " dia. X $\frac{1}{2}$ " L. ...	1
594	25165	Control tube (to 2nd and 3rd gears)	1
595		Control rod (to 1st and rev. gears)	1
595	25172	Universal joint (2nd and 3rd gears)	1
596	25332	Control arm (2nd and 3rd gears)	1
597		Control arm clamping bolt $\frac{1}{8}$ " B.S.W. X 1" L. ...	2
598	G.155	Control arm key ...	2
599	25166	Universal joint (1st and rev. gears)	1
600	25331	Control arm (1st and rev. gears)	1
601			1
602			1
603	25320	Positioning arm ...	1
604		Fulcrum bolt $\frac{1}{4}$ " B.S.W. X $\frac{1}{2}$ " L. ...	1
605	G.465	Positioning pin ...	1
606		Washer $\frac{1}{16}$ " dia. ...	1
607	G.466	Split pin $\frac{3}{32}$ " dia. X $\frac{1}{2}$ " L. ...	1
607		Spring ...	1
608			1
609	25222	Control quadrant ...	1
610	G.781	Control hand lever ...	1
611	G.792	Hand lever spring ...	1
612		Nut $\frac{1}{8}$ " B.S.W. slotted ...	1
612	G.793	Split pin $\frac{3}{32}$ " dia. X 0" L. ...	1
613		Rotor control rod ...	1
614		Split pin $\frac{3}{32}$ " dia. X $\frac{3}{8}$ " L. ...	1
615		Control rod spring ...	1
616	G.794	Trunnion ...	1
617	G.773	Washer $\frac{1}{16}$ " dia. ...	1
618		Slotted nut $\frac{1}{8}$ " B.S.W. ...	1
619		Split pin $\frac{3}{32}$ " dia. X $\frac{3}{8}$ " L. ...	1
620		Locknuts $\frac{1}{8}$ " B.S.W. ...	1
621	G.152	Rotor control arm ...	2
622	G.155	Control arm key ...	1
623	G.321	Control arm clamping bolt $\frac{1}{8}$ " B.S.W. X 1" L. ...	1
624		Differential lock control rod ...	1
625	G.324	Split pin $\frac{3}{32}$ " dia. X $\frac{3}{8}$ " L. ...	1
626	G.773	Control rod spring ...	1
627		Trunnion ...	1
628		Washer $\frac{1}{16}$ " dia. ...	1
629		Slotted nut $\frac{1}{8}$ " B.S.W. ...	1
630		Split pin $\frac{3}{32}$ " dia. X $\frac{3}{8}$ " L. ...	1
631		Slotted nut $\frac{1}{8}$ " B.S.W. ...	1
632		Split pin $\frac{3}{32}$ " dia. X $\frac{3}{8}$ " L. ...	1
633		Differential lock selector quadrant ...	1
634		Quadrant pin ...	1
635	25356	Split pin $\frac{1}{8}$ " dia. X $\frac{1}{2}$ " L. ...	1
636	25352	Trunnion ...	1
637	G.319	Locknuts $\frac{1}{4}$ " B.S.W. ...	2

HANDLEBAR CONTROL (Plate 8)

ROTOR AND DIFFERENTIAL CONTROL (Plate 8)

CLUTCH CONTROL (Plate 8)

629	25145	Hand lever ...	1
630	G.699	Hand lever fulcrum rivet ...	1
631	25149	Pivot pin ...	1
632		Split pin $\frac{1}{8}$ " dia. X $\frac{1}{2}$ " L. ...	1
633	25150	Adjusting link ...	1
634		Locknut $\frac{1}{8}$ " B.S.W. ...	1
635	25170	Control rod, hand lever to frame arm ...	1
636		Washer $\frac{1}{8}$ " dia. ...	1
637	25144	Frame arm ...	1
638		Frame arm pivot bolt $\frac{1}{4}$ " B.S.W. X 1" L. ...	1
639	25446	Locknut $\frac{1}{4}$ " B.S.W. ...	1
640		Rod, frame arm to control arm ...	1
641	25412	Split pin $\frac{3}{32}$ " dia. X $\frac{3}{8}$ " L. ...	1
642	25410	Control rod spring ...	1
643		Trunnion ...	1
644		Slotted nut $\frac{1}{8}$ " B.S.W. ...	1
645		Split pin $\frac{3}{32}$ " dia. X $\frac{3}{8}$ " L. ...	1
646		Wing nut ...	1
647		Control arm ...	1
648		Control arm key ...	1
649		Control arm clamping bolt $\frac{1}{8}$ " B.S.W. X 1" L. ...	1

DECOMPRESSOR CONTROL (Plate 8)

645	G.188	Hand lever ...	1
646		Split pin $\frac{3}{32}$ " dia. X $\frac{3}{8}$ " L. ...	1
647	G.789	Trunnion ...	1
648		Split pin $\frac{1}{8}$ " dia. X $\frac{3}{8}$ " L. ...	1
649		Control rod ...	1

REVERSE INTERLOCK (Plate 8)

649	25132	Rocker ...	1
650	25153	Rocker pin ...	1
651		Split pins $\frac{1}{8}$ " dia. X 1" L. ...	2
652		Linking setscrew $\frac{1}{4}$ " B.S.W. X $\frac{3}{8}$ " L. ...	1
653		Locknut $\frac{1}{4}$ " B.S.W. ...	1
654	25152	Vertical link ...	1
655	25181	Tension rod ...	1
656	25178	Special washers ...	2
657	25130	Spring ...	1
657-660		Tensioning nut $\frac{1}{8}$ " B.S.W. ...	1

PICKTYNE ROTOR ASSEMBLY (Plate 9)

Note—Picktyne rotor will be supplied complete with stub axle to facilitate fitting.

661	25473	Picktyne rotor (7 flanges, 24" machine)	1
662	G.922	Picktyne rotor (9 flanges, 30" machine)	8
663	G.921	End flange bolts ...	4 per flange
664		Intermediate flange bolts ...	4 per flange
665		Spring washers $\frac{1}{8}$ " dia. ...	4 per flange
666		Nut $\frac{1}{16}$ " B.S.F. ...	4 per flange
667	991	Picktyne, Lucerne } Alternatives ...	2 per flange
668	992	Picktyne chisel ...	2 per flange

DEPTH CONTROL WHEEL ASSEMBLY (Plate 9)

Standard fitting for 30" model, alternative to skid for 24" machine.

666-669	spare		
670	G.664	Pedestal	..
671	G.663	Arm	..
672	G.666	Swivel pin	..
673	G.660	Split pin $\frac{1}{8}$ " dia. X 1" L.	..
674	G.661	Wheel	..
675	G.661	Axle	..
676	G.665	Axle locknut $\frac{3}{8}$ " B.S.W.	..
677	G.659	Locking washer	..
678	G.657	Wheel bush	..
679	G.658	Inner dust cover	..
680	G.658	Outer dust cover	..
681	G.662	Wheel cap	..
682		Oiling screw $\frac{1}{4}$ " B.S.W. Rd. Hd. X $\frac{3}{8}$ " L.	..

POWER TAKE-OFF ASSEMBLY (24" machine only) (Plate 9)

683-689	spare		
690	25475	Housing	..
691		Housing bolt $\frac{3}{8}$ " B.S.W. X 2 $\frac{1}{2}$ " L.	..
		Spring washer $\frac{3}{8}$ " dia.	..
		Nut $\frac{3}{8}$ " B.S.W.	..
692		Oiling screw $\frac{1}{4}$ " B.S.W. Rd. Hd. X $\frac{1}{2}$ " L.	..
693	25477	Shaft	..
694	G.939	Shaft key	..
695	G.932	Thrust collar	..
696	G.936	Ball bearing	..
697	G.935	Bearing dust cover	..
698	G.938	Shaft nut	..
699	G.940	Pulley wheel	..
700	G.941	Starting handle	..

EXTENSION RIMS FOR CLEATED LAND WHEELS

(Plate 9)

701-709	spare		
710	G.135/1	Land wheel extension flange	..
711	24G.135/3	Land wheel extension rim (24" machine)	..
712		Flange bolt $\frac{3}{8}$ " B.S.W. X 1" L.	..
713		Rim attachment bolt $\frac{3}{8}$ " B.S.W. X 1 $\frac{1}{2}$ " L.	..
		Spring washer $\frac{3}{8}$ " dia.	..
		Nut $\frac{3}{8}$ " B.S.W.	..
714-716	spare		

EXTENSION HUBS FOR DOUBLE PNEUMATIC TYRED WHEELS

(Plate 9)

Standard for 30" machine, optional fitting for 24" machine.			
717	25396	Hub, R.H.	..
717	25397	Hub, L.H.	..
718	25393	Studs, R.H.	..
718	25394	Studs, L.H.	..

(Tyres cannot be supplied as spares by us. Pneumatic tyres and their wheels will be supplied as required; see Plate 7.)
 N.B.—The double pneumatic wheels required are THREE right hand, Pt. No. B.132 and one left hand, Pt. No. G.131).

PICKTYNE ROTOR, DEPTH CONTROL WHEEL, POWER TAKE-OFF, ROAD WHEEL EXTENSION, HUBS AND RIMS




PLATE 9

STARTING HANDLES FOR USE WITH EXTENSION RIMS AND HUBS

(Plate 9)

719					
720	25561	For 24" machine fitted with extension rims	...	1	
720	25395	For 24" machine fitted with twin tyres (N.B.—The appropriate handle will be supplied whichever wheel extensions are ordered.)	...	1	

SOIL SHREDDER (24" model only) (Plate 10)

721-724	spare				
725	24G.1000	Trough	...	1	
726	G.1001	Feeder blade	...	2	
727	G.919	Feeder blade bolt	...	4	
		Spring washer $\frac{1}{16}$ " dia.	...	4	
		Nut $\frac{1}{8}$ " B.S.F.	...	4	
728	24G.1002	Soil screen, coarse	...	1	
728	24G.1004	Soil screen, fine	...	1	
729	G.1003	Hook bolt	...	2	
		Spring washer $\frac{3}{8}$ " dia.	...	2	
		Nut $\frac{3}{8}$ " B.S.W.	...	2	
730-734	spare				

FURROWING ATTACHMENT (Plate 10)

735	G.952	Mould board	...	1	
736		Clamping bolt $\frac{1}{2}$ " B.S.W. X 1" L.	...	1	
		Nut $\frac{1}{2}$ " B.S.W.	...	1	

FURROW COVERING ATTACHMENT (Plate 10)

737		Attachment complete	...	1	
738	G.951				
739					

ROLLER ASSEMBLY (24" model only) (Plate 10)

740	24G.1007	Roller fork	...	1	
741	24G.1017	Roller scraper	...	1	
742		Scraper clamping bolt $\frac{1}{2}$ " B.S.W. X 1" L.	...	2	
		Flat washer $\frac{1}{2}$ " dia.	...	2	
		Spring washer $\frac{1}{2}$ " dia.	...	2	
		Nut $\frac{1}{2}$ " B.S.W.	...	2	
743	24G.1005	Roller drum	...	1	
744	G.1011	Roller filler plate	...	1	
745		Setscrew $\frac{1}{4}$ " B.S.W. Rd. Hd. X $\frac{3}{8}$ " L.	...	2	
		Spring washer	...	2	
746	G.1012	Grease nipple $\frac{1}{4}$ " B.S.P.	...	2	
747	24G.1006	Axle	...	1	
748	G.1008	Axle bush	...	2	
749		Axle nut $\frac{3}{8}$ " B.S.W. locknut	...	2	
		Axle spring washer $\frac{3}{8}$ " dia.	...	2	

WICO MAGNETO TYPE, A-1137 BZ. (Plate 11)

ZX.207		Drive shaft adaptor assembly (comprising the following—	...	1	
		Drive shaft adaptor nut	...	1	
801	I365A	Drive shaft adaptor nut lock washer	...	1	
802	M.12LXB	Drive shaft adaptor nut key	...	1	
803	I146D	Drive shaft adaptor	...	1	
804	E.113XA	Rotor assembly	...	1	
805	X.1399M	Breaker cam key	...	1	
806	I146				

SOIL SHREDDER, FURROWING ATTACHMENT, FURROW COVERING ATTACHMENT, ROLLER





PLATE 10

PLATE II

Illust. No.	Part No.	Description	No. off
807	FX.193	End plate group (comprising the following)—	1
808	B.33X	Oil seal	1
809	F.153	End plate	4
810	A.72XC	End plate screw	1
810	I.VA-715	End plate gasket	1
811	X.1669C	Oiling disc unit (comprising the following)—	1
812	I.VA-487	Oiling disc	1
813	1379	Main oil pad	1
814	X.2505B	Main oil pad spring	1
814	X.1487	Oil scraper assembly	1
815	GX.1414EPM	Main housing group (comprising the following)—	1
816	X.1414EPM	Main housing unit (includes items 816 & 817)	2
816	2495	Main housing bushing	2
817	1423	Oiler	2
818	X.1596	Earth stud group (2 screws, connecting wire and breaker lead)	1
819	I.XA.862	Earth stud fibre washer	2
820	M.34X	Earth stud fibre insulating bushing	6
821	B.140X	Stop button unit (comprising the following)—	2
822	B.138X	Stop button contact	2
823	I.XA.862	Earth stud fibre washer	2
824	I.XA.256	Earth stud washer	2
OR	A.142X	Earth stud nut (right side)	1
OR	M.72	Earth stud nut (left side)	1
825	X.1411	Coil and core group (comprising the following)—	1
826	X.1409	Coil core group	1
827	X.1410	Coil group	2
828	2264B	Coil wedge	2
829	1384	Coil core clamp	2
830	M.126XB	Coil core clamp screw	2
830	M.55XA	Coil core clamp screw lock washer	2
831	X.1412	Cover group (comprising the following)—	1
832	X.2009	Cover unit (includes items Nos. 836, 837 & 838)	1
833	1385	Cover gasket	4
834	1117	Cover screw	4
835	I.XA-256	Cover screw washer	4
836	1118	Cover screw leather washer	4
837	1328	Coil contact screw	1
838	M.55XA	Coil contact screw lock washer	1
838	1397	Coil contact	1
839	X.1615Z	Secondary interlead group	1
840	IKFP.121	H.T. lead group (16°)	2
841	X.1622B	Distributor cap cover (includes item No. 842)	1
842	16-159	Distributor cap gasket	1
843	X.NC-74	Rotor arm contact bush group (comprising the following)—	1
844	1216	Rotor arm contact bush	1
844	1217	Rotor arm contact bush spring	1
845	16-X.477B	Rotor arm	1
846	X.1878B	Breaker assembly (comprising the following)—	1
847	X.1408B	Breaker arm group	1
848	M.31X	Breaker arm clamp screw	1
849	M.55XA	Breaker arm clamp screw lock washer	1
849	1207	Breaker arm clamp washer	1



Illust. No.	Part No.	Description	No. off
850	1418	Breaker arm bearing bush	1
851	1197	Breaker arm spring washer	1
852	1197B	Breaker arm spring shim	2
853	6017	Breaker arm spring screw	1
854	1196	Fixed contact	1
855	M.31X	Fixed contact screw	1
856	M.54X	Fixed contact screw lock washer	1
857	1-XA.256	Fixed contact screw washer	1
858	16-818B	Breaker box insulation strip	1
859	X.2175B	Breaker assembly housing	1
860	X.1413	Condenser group (includes items 862 & 863)	1
861	5446M	Breaker cam oil pad	1
862	1100	Condenser screw	2
863	M.900	Condenser screw lock washer	2
	X.1561	Breaker cam unit (comprising the following)—	
864	1107	Breaker cam	1
865	1381	Cam screw lock plate	1
866	M.31X	Cam screw	1
867	M.55XA	Cam screw lock washer	1
868	X.1700	Distributor cap clip assembly	2
869	2073	Breaker box screw	2
870	M.55XA	Breaker box screw lock washer	2

